




Appendix A — Cable Diagrams


Cable C1300. DB15M To V.35 Block




Cable C1500 —AES Adapter  
DB9M




Cable C1700 — Ancillary Data And RS232 Cable  
DB9F



Cable C1800 — Rear Panel RS232 Remote Control Cable  
DB9M



Cable C1900 — Rear Panel RS485 Remote Control Cable



## Appendix B — Rear Panel Connectors

### Audio Input

Connector: Female XLR

1	Ground
2	+
3	-

### Audio Output

Connector: Male XLR

1	Ground
2	+
3	-

### AES/EBU

Connector: AMP 747158-8 (Female DB9)

#### Digital Audio Input

1	IN+
6	IN-
2	Ground

#### Digital Audio Output

4	OUT +
9	OUT -
5	Ground

#### Digital Audio Sync Input

3	SYNC IN +
7	SYNC IN -
8	Ground

### RS232/RS485 Remote Control

Connector: AMP 747150-8 (Female DB9)

#### RS232 (rear panel remote control port)

4	RD (input)
9	TD (output)
5	Ground

#### RS485

1	RD- (Input)
6	RD+ (Input)
2	TD- (Output)
7	TD+ (Output)
3	Ground

### Ancillary Data

Connector: AMP 747871-8 (Male DB9)

1	DCD	Input
2	RXD	Input
3	TXD	Output
4	DTR	Output
5	Ground	
6	DSR	Input
7	RTS	Output
8	CTS	Input
9	no connection	

## Alarm Relay

Connector: AMP 747871-8 (Male DB9)

1	Common 1
2	no connection
3	Normal 2 (power on and no summary alarm (RLS) )
4	Common 2
5	Alarm 1 (power off or summary alarm (RLS) )
6	no connection
7	Alarm 2 (power off or summary alarm (RLS) )
8	no connection
9	Normal 1 (power on and no summary alarm (RLS) )

## DIF101, DIF102

## X.21

Connector: DB15F

1	fg	Frame ground
	t(a)	Transmit data A (output)
	c(a)	Control element A
4	r(a)	
5	i(a)	(input)
6		Timing element A (input)
	b(a)	Byte timing B (input)
	sg	Signal ground
	t(b)	Transmit data B (output)
	c(b)	Control element B
11	r(b)	
12	i(b)	(input)
13		Timing element B (input)
14		Byte timing B (input)
15		

## V.35

Connector: DB15F

	fg	Frame ground
	t(a)	Transmit data A (output)
	rts	Request to send
	rda	Receive data A (input)
		N/C
6		Receive timing A (input)
7		Transmit timing A (output)
	Sg	Signal ground
	tdb	Transmit data B (output)
	dtr	Data terminal ready
	rdb	Receive data B (input)
	rlsd	Receive line signal detect
13	retb	
14	tetb	(output)
15		Clear to send

## Appendix C — Factory Defaults

The factory default values are as follows:

CAA 1 YES		set auto answer on for line 1
CAA 2 YES		set auto answer on for line 2
CAC NO		set to no auto reconnect
CAN 2		set ancillary data port to configuration 2 (mux)
CBR 128		set loopback digital interface bit rate
CBZ NO		internal alarm buzzer inactive
CCV 7		set LCD contrast
CDC NO		don't display connect time
CDM		clear dialing parameters
CDR 9600		set decoder DSP ancillary data rate
CEA LN0	!OI0	set default link actions
CEA LN1	!OI1	
CEA LN2	!OI2	
CEA LN3	!OI3	
CEA LN4	!OI4	
CEA LN5	!OI5	
CEA LN6	!OI6	
CEA LN7	!OI7	
CEA LN10	BER	
CEA LN11	OOF	
CEA ESM	!EPL	
CEA DSM	!DPL # BER # OOF	
CEA RLS	EPL & DPL & !BER & !OOF	
CEA RL0	LN0	
CEA RL1	LN1	
CEA RL2	LN2	
CEA RL3	LN3	
CEA RL4	LN4	
CEA RL5	LN5	
CEA RL6	LN6	
CEA RL7	LN7	
CEA SC1	CI1	
CEA RC1	LN8	
CEA VA0		all Virtual Actions cleared
CEA VA1		
CEA VA2		
CEA VA3		
CFM 4 Wires		set rear panel 485 port to 4 wires

CFP NO	set no front panel remote control protocol
CGH OLDPKI	set to old PKI framing in H.221 mode
CHK 1	clear all hot keys
CHK 2	
CID 0	set to RS485 ID 0
CIF 1 NONE	set to no digital interface
CIF 2 NONE	set to no digital interface
CLB 1 NORM	set no digital loopback on DIF 1
CLB 2 NORM	set no digital loopback on DIF 2
CLI STATUS 10	set status led intensity
CLL A ON	set all speed dialing
CMA 2400	set mux ancillary data 2400 baud
CPC NO	no protocol for remote communications
CRB 9600	set remote control baud rate
CRD 1	set number of TA redial attempts to 1
CRE YES	set to echo rear panel commands
CRI 232	RS232 for remote communication
CRM 4WIRES	set RS485 remote control port to 4 wire
CSL LB	system loopback
CSP RS232	set sync anc data interface to RS232
CTC NONE	no connection to any TA
CTM 0 0	turn off timer 0
CTM 1 0	turn off timer 1
CTM 2 0	turn off timer 2
CTM 3 0	turn off timer 3
CTO 15	set TA dialing time-out in seconds
CVA 0	set virtual action 0 to empty
CVA 1	set virtual action 1 to empty
CVA 2	set virtual action 2 to empty
CVA 3	set virtual action 3 to empty
DAF CCS	set decoder ancillary data format
DAL MPEG L2	set to MPEG I layer 2
DCO ISOCCS	set decoder decoding mode to ISO and CCS
DCS NORM	set decoder output to no copy or swap
DDO 48	set to 48 kHz digital output
DES NOTREQ	set decoder AES sync timing not required
DIN NO	set decoder to operate together with encoder
DMD NORM	set decoder maintenance diagnostic mode to normal
DMU NONE	set decoder mute to none
DSP NO	set to no decoder scale factor
DTI NORMAUTO	set decoder timing to normal
EAF CCS	set encoder ancillary data format
EAI A	set input to analog

**EAL MPEG2****EAM JS**set to joint stereo  
set to no mono mix**ESR 48****EBR 128**set encoder to 128K bit rate  
set no copyright bit**ECS NORM****EEP NO**set no emphasis bit  
set encoder line format to 2 line, line 1 & 2**ELU 1****EOR NO**set no original bit  
set no privacy bit off**EPR YES****EPY 0 1**set psychoacoustic parameter type  
set psychoacoustic parameter type**EPY 2 1****EPY 3 2**set psychoacoustic parameter type  
set psychoacoustic parameter type**EPY 5 3****EPY 6 1**set psychoacoustic parameter type  
set psychoacoustic parameter type**EPY 8 1****EPY 9 3**set psychoacoustic parameter type  
set psychoacoustic parameter type**EPY 11 3****EPY 12 4**set psychoacoustic parameter type  
set psychoacoustic parameter type**EPY 14 1****EPY 15 3**set psychoacoustic parameter type  
set psychoacoustic parameter type**EPY 17 3****EPY 18 4**set psychoacoustic parameter type  
set psychoacoustic parameter type**EPY 20 3****EPY 21 3**set psychoacoustic parameter type  
set psychoacoustic parameter type**EPY 23 1****EPY 24 1**set psychoacoustic parameter type  
set psychoacoustic parameter type**EPY 26 4****EPY 27 3**

set psychoacoustic parameter type

EPY 28 4	set psychoacoustic parameter type
EPY 29 4	set psychoacoustic parameter type
EPY 30 1	set psychoacoustic parameter type
EPY 31 1	set psychoacoustic parameter type
ESD OFF	set encoder sine wave detector off
ESP NO	set to no encoder scale factor protection
ESW CI0 OFF	set simulated switch 0 open
ESW CI1 OFF	set simulated switch 1 open
ESW CI2 OFF	set simulated switch 2 open
ESW CI3 OFF	set simulated switch 3 open
ESW CI4 OFF	set simulated switch 4 open
ESW CI5 OFF	set simulated switch 5 open
ESW CI6 OFF	set simulated switch 6 open
ESW CI7 OFF	set simulated switch 7 open
ETI NORM	set encoder timing to normal
MBD 1	set BER count down counter
MBE NO	disallow remote boot
MBL 1	set BER limit to 1
MBP 10	set BER maximum count at 10
MBR	clear the BER counter
MBU 1	set BER count up counter
MBX ON	set keypad clicker on
MCP NONE	set to no connect port
MET DISABLED	disable hardware tests
MLK KEYPAD NO	set no command lockout from keypad
MLK INBAND NO	set no command lockout from inband
MLK FRONT NO	set no command lockout from front panel
MLK REAR NO	set no command lockout from rear panel
MLK DIF NO	set no command lockout from digital
MLK VA NO	set no command lockout from virtual
MOD 1	set OOF down counter
MOL 10	set OOF limit to 10
MOP 20	set OOF count maximum
MOU 2	set OOF up counter
MQL EL -60	set encoder left quiet threshold level
MQL ER -60	set encoder right quiet threshold level
MQL DL -60	set decoder left quiet threshold level
MQL DR -60	set decoder right quiet threshold level
MQL E -60	set encoder stereo quiet threshold level
MQL D -60	set decoder stereo quiet threshold level
MQT EL 10	set encoder left quiet threshold time
MQT ER 10	set encoder right quiet threshold time
MQT DL 10	set decoder left quiet threshold time

MQT DR 10	set decoder right quiet threshold time
MQT E 10	set encoder stereo quiet threshold time
MQT D 10	set decoder stereo quiet threshold time
MRS RP	set rear panel remote control source to rear
MTM NONE	set to no test measurements
MWP NONE	set to no watch port

## Appendix D - Useful Pull-Outs

Entry	Description	Bit rate	Sample rate	Encoder algorithm	Mode	Line format	Decoder indep.	Zephyr compatible	RoadRunner equivalent
0	CDQ1000_24K:QS	64	24	CCSN	M	L1	NO	NO	6
1	CDQ20002LNS:QS	128	48	MPEGL2	JS	CCSL12	NO	NO	
2	H221_2LINES:QS	128	48	MPEGL2	JS	H221L12	NO	NO	
5	MICRO56:QS	56	16	G.722	M1	L1	NO	YES	40
6	G.722_56K:QS	56	16	G.722	M1	L1	NO	YES	40
7	G.722_64K:QS	64	16	G.722	M1	L1	NO	YES	42
8	MPEGL2/64K:QS	64	48	MPEGL2	M	L1	NO	NO	10
9	MPEGL2/56K:QS	56	48	MPEGL2	M	L1	NO	NO	4
10	CCSN/64K:QS	64	48	CCSN	M	L1	NO	NO	10
11*	CCSTEST64	64	48	MPEGL2	M	L1	NO	NO	
12*	CCSTEST128	128	48	MPEGL2	JS	CCSL12	NO	NO	
13*	CCSTESTH221	128	48	MPEGL2	JS	H221L12	NO	NO	
14*	CCSTEST56	56	48	MPEGL2	M	L1	NO	NO	
15*	CCSTEST112	112	56	MPEGL2	JS	CCSL12	NO	NO	
16	CDQ1000/56K:QS	56	24	CCSN	M	L1	NO	NO	0
17	CDQ2000/112:QS	112	48	MPEGL2	JS	CCSL12	NO	NO	
18	CCSN/56K:QS	56	48	CCSN	M	L1	NO	NO	4
19	G.722_H.221:QS	64	16	G.722	M1	H221L1	NO	NO	44
20	CCSN/128K:QS	128	48	CCSN	JS	CCSL12	NO	NO	
21	CCSN/112K:QS	112	48	CCSN	JS	CCSL12	NO	NO	
22	CDQ2001/128:QS	128	32	MPEGL2	JS	CCSL12	NO	NO	
23	CDQ2001/112:QS	112	32	MPEGL2	JS	CCSL12	NO	NO	
24	ZEPHYR/56K:QS	56	48	MPEGL2	M	L1	YES	YES	5
25	ZEPHYR/64K:QS	64	48	MPEGL2	M	L1	YES	YES	11
26	ZEPHYR/112K:QS	112	48	MPEGL2	JS	CCSL12	YES	YES	
27	ZEPHYR/128K:QS	128	48	MPEGL2	JS	CCSL12	YES	YES	
28	LYR3/56K:QS	56	48	MPEGL3	M	L1	NO	NO	24
29	LYR3/64K:QS	64	48	MPEGL3	M	L1	NO	NO	30
30	LYR3IND56:QS	56	48	MPEGL3	M	L1	YES	YES	25
31	LYR3IND64:QS	64	48	MPEGL3	M	L1	YES	YES	31
32	LYR3IND56/32:QS	56	32	MPEGL3	M	L1	YES	YES	23
33	LYR3IND64/32:QS	64	32	MPEGL3	M	L1	YES	YES	29
34	ROADRUN112:QS	112	48	MPEGL2	M	CCSL12	NO	NO	14
35	ROADRUN128:QS	128	48	MPEGL2	M	CCSL12	NO	NO	18
36	ZEPH112MONO:QS	112	48	MPEGL2	M	CCSL12	YES	YES	15
37	ZEPH128MONO:QS	128	48	MPEGL2	M	CCSL12	YES	YES	19

\* — These entries dial numbers, and will not work unless an internal terminal adapter is used and an ISDN line is connected.



## Appendix E — Specifications

All published specifications are typical and subject to change without notice.

### *ANALOG AUDIO SPECIFICATIONS*

Connector Type:	Gold plated Neutrik® 3-pin XLR
Input:	female
Output:	male
A/D & D/A converters:	24 bit sigma-delta
Sample frequencies:	16, 24, 32, or 48 kHz
Input impedance:	600 Ohms or >25 kOhm, balanced
Output impedance:	600 Ohms or < 60 Ohms, balanced
Clipping level:	+12, +15 or +18 dBu, $\pm 1$ dB
Insertion gain:	0 dB $\pm 0.5$ dB
System frequency response:	$\pm 0.3$ dB, ref. @ 1 kHz. MUSICAM Layer II.
Fs = 16 KHz	20 to 7,500 Hz
FS = 24 KHz	20 to 11,250 Hz
System frequency response:	$\pm 0.15$ dB, ref. @ 1 kHz. MUSICAM Layer II and Layer III.
Fs = 32 KHz	20 to 14,500 Hz
FS = 48 KHz	20 to 20,000 Hz
Total harmonic distortion:	<-80 dB @ 1 KHz
Signal-to-noise ratio:	>92 dB
Crosstalk:	<-85 dB
L/R phase difference:	<0.5°
Compression algorithms:	CCS MUSICAM® old CCS MUSICAM® new ISO/MPEG Layer II ISO/MPEG Layer III CCITT G.722 Storage for additional algorithms

*DIGITAL AUDIO SPECIFICATIONS*

Connector type:	DB9, female    optional XLR adapter available
Interface type:	AES/EBU or S/PDIF
Lock range:	$\pm 200$ ppm
Rate adaption:	Automatic

*DATA INTERFACE SPECIFICATIONS*

Network interface types:	ISDN BRI (2B + D), RS422, V.35, X.21
Number of ISDN B channels supported:	1 to 6 in parallel
Bit rates:	Layer II: 24, 32, 40, 48, 56, 64, 80, 96, 112, 128, 144, 160, 192, 224, 256, 320 or 384 kb/s.
	Layer III: 56, 64, 112, 128, 192, 256 or 320 kb/s
	G.722 56 or 64 kb/s
Auxiliary data channel	
Type of connector:	DB9, female
Bit rate, direct mode:	300, 1,200, 2,400, 9,600, or 38,400 bps
Bit rate, Mux mode	300, 1,200, 2,400, 9,600, or 19,200 bps
Mode:	8 data bits, 1 stop bit
Handshake:	None required
Alarm interface	
Type of connector:	DB9, male
Functions:	Summary alarm
Type:	Form C contacts

*CONTROL INTERFACES*

Level indicators:	Norm and Clip LED
Remote control, rear panel:	
Features controlled:	All
Electrical interfaces:	RS232-C or RS485
Connector:	DB9, male
Bit rates:	1,200, 2,400, 4,800, 9,600, or 38,400 bits/s
Mode:	8 data bits, 1 stop bit, no parity
Handshake:	None or XON/XOFF
Digital Control Outputs:	
Type:	Dry floating relay or open collector TTL
Number:	1 DPDT
Connector:	DB9, female

## GENERAL

### Environmental Conditions:

Storage temperature: -40 to +70° C (-40 to +158° F)

Operating temperature: 5 to +45° C (41 to +113° F)

Relative humidity: 20 to 80%, non-condensing

EMC: EN 50081-1, EN 50082-2

Power requirements: 90 to 250 VAC, 47 to 65 Hz. <60 Watts

### Dimensions, Models 210, 220, and 230:

Height: 2U (3.5", 8.89 cm)

Width: 19" (48.26 cm), rack mountable

Depth: 12.2" (30.99 cm)

Net weight: Approx. 14.4 lbs. (6.6 Kg)

## DELAY MEASUREMENTS

The following measurements are typical,  $\pm 20\%$

Bit Rate	Sample Rate	Algorithm	Line Fmt	M	JS	DM	S	M1
64	16	MPEGL2	L1	190	200	200	200	
64	24	MPEGL2	L1	140	135	135	135	
64	32	MPEGL2	L1	100	100	100	100	
64	48	MPEGL2	L1	70	70	70	75	
64	16	G.722	L1	-	-	-	-	35

The following measurements are for the CCS 2-Line mode. Low-delay single-line delay figures are typically  $\frac{1}{2}$  those shown here.

128	16	MPEGL2	CCSL12	-	-	-	-
128	24	MPEGL2	CCSL12	265	265	265	265
128	32	MPEGL2	CCSL12	230	230	230	230
128	48	MPEGL2	CCSL12	135	130	160	160

### *Frequency Response and Noise Specifications*

The following plots are representative of performance at the most popular configurations. These measurements were taken using the Audio Precision System One, Dual Domain analyzer and the standard test suite.

## Appendix F — ISDN Ordering And Provisioning

### North American ISDN Ordering Contacts

Ameritech	800-TEAMDATA
AT&T	800-222-7956
Bell Atlantic	800-570-ISDN
Bellcore	800-992-ISDN
BellSouth	800-428-ISDN
Cincinnati Bell	800-566-DATA
GTE	800-888-8799
MCI	800-MCI-ISDN
Nevada Bell	702-333-4811
Pacific Bell	800-4PB-ISDN
Rochester Telephone	716-777-1234
SNET	203-553-2369
Sprint	913-624-4162
Stentor Canada	800-578-ISDN
Southwestern Bell	800-992-ISDN
US West	800-246-5226 or 303-896-8301
Wiltel	918-588-5069

### North American ISDN Provisioning

In an effort to make ISDN ordering and provisioning as easy as possible, we recommend faxing the following five pages to your ISDN service provider. If provisioned as shown on these pages, your ISDN circuit will work with your **CDQPrima**, regardless of terminal adapter used. If given a choice between AT&T Custom or National ISDN, we recommend National ISDN. Also note that **when ordering ISDN service, you must ask for long distance service and specify a carrier.** Unlike regular telephone service, long distance is not automatically provided.

<i>FAX-PAGE 1</i>
-------------------

**AT&T 5ESS Custom**

Request from the telephone company an ISDN line in a “Point To Point” configuration with 2B1Q line code. Your ISDN line must be configured to allow circuit switched data on both B-channels and signaling on the D-channel. Request that the telephone company program your ISDN line with the following attributes:

- Maximum terminals set to 1 (this tells the switch that there is 1 terminal active on this line.)
- Maximum B-channels set to 2; Actual User settings (this tells the switch that you are an actual user and may use both B-channels simultaneously.)
- Circuit switched data set to 2; circuit switched data channel set to any (this tells the switch that you may use both B-channels simultaneously. The “Any” tells the switch that either B-channel can be used for data.)
- Terminal type is Type A - Basic Terminal (this tells the switch you are a basic ISDN terminal.)
- Display set to Yes (this tells the switch that you have display capabilities.)
- Call appearance quantity set to 1 (this tells the switch that you want 1 appearance of your primary telephone number.)
- Call appearance preference set to Idle (this tells the switch that your software will make a positive choice of which call appearance it will use to initiate a call.)

The Telephone Company will also need to know any additional voice features that you require on your ISDN lines. Examples of these features are Caller ID and Call Forwarding. PLEASE REMEMBER TO SPECIFY A LONG DISTANCE CARRIER.

**FAX-PAGE 2****AT&T 5ESS - National ISDN 1**

Request from the telephone company a National ISDN 1 ISDN line in a “multipoint” configuration with 2B1Q line code. The optional “multipoint” configuration will allow you to have a separate telephone number for each B-channel; however, it will physically be only one ISDN line. The Telephone Company should supply you with a different telephone number and SPID (Service Profile Identification) for each B-channel in a multipoint arrangement. Your ISDN line must be configured to allow circuit switched data on both B-channels and signaling on the D-channel. Request that the Telephone Company program your ISDN line with the following attributes:

- Maximum terminals set to 2 (this tells the switch that there are 2 terminals active on this line.)
- Maximum B-channels set to 2; Actual User settings (this tells the switch that you are an actual user and may use both B-channels simultaneously.)
- Circuit switched data set to 2; circuit switched data channel set to any (this tells the switch that you may use both B-channels simultaneously. The “Any” tells the switch that either B-channel can be used for data.)
- Terminal type is Type A - Basic Terminal (this tells the switch you are a basic ISDN terminal.)
- Display set to Yes (this tells the switch that you have display capabilities.)
- Circuit switched data limit set to 2 (this tells the switch that you may receive 2 data calls.)
- Call appearance preference set to Idle (this tells the switch that your software will make a positive choice of which call appearance it will use to initiate a call.)

The Telephone Company will also need to know any additional voice features that you require on your ISDN lines. Examples of these features are Caller ID and Call Forwarding. PLEASE REMEMBER TO SPECIFY A LONG DISTANCE CARRIER.

<b>FAX-PAGE 3</b>
-------------------

AT&T 5ESS -Custom

- 2B1Q line code
- 2B&D line - Point To Point
  - B1 - circuit switched voice/data
  - B2 - circuit switched voice/data
  - D - signaling only
  - set MTERM to 1
  - set MAXB CHNL to 2; ACT USR to Y
  - set CSD to 2; CSD CHL to ANY
  - set TERMTYP to TYPE-A; DISPLAY to Y
  - set CA QTY to 1
  - set CA PREF to I
- list any additional data features required
- specify long distance carrier

AT&T 5ESS -National ISDN

- 2B1Q line code
- 2B&D line - Standard
  - B1 - circuit switched voice/data
  - B2 - circuit switched voice/data
  - D - signaling only
  - set MTERM to 2
  - set CHNL to 2; ACT USR to Y
  - set CSD to 2; CSD CHL to ANY
  - set TERMTYP to TYPE-A; DISPLAY to Y
  - set CSD limit to 2
  - set CA PREF to I
- Optional - multipoint; different DN for each B-channel, but same OE (office equipment.)
- list any additional data features required
- specify long distance carrier

## FAX-PAGE 4

## Northern Telecomm DMS-100 BC-35 National ISDN 1

Request from the telephone company a National ISDN 1 ISDN line with 2B1Q line code. Your ISDN line must be configured to allow circuit switched data on both B-channels and signaling on the D-channel. The telephone company should supply you with a separate telephone number and SPID (Service Profile Identification) for each B-channel; however, it will physically be only one ISDN line. Request that the Telephone Company program your ISDN line with the following attributes:

B1 and B2 should be set as follows:

- Set the circuit switch option to Yes; set the barrier restriction option to no packet mode data (NOPMD) only (this tells the switch that you require circuit switch ability on your B-channel, The bearer restriction on your line means that you are not allowed packet data on your B-channel.)
- Set protocol to function version 2; (PVC2) (this tells the switch that your CPE software is using National ISDN 1 protocol.)
- Set the service profile identification (SPID) suffix to 1 (this tells the switch that the digit following your telephone number will be 1. The SPID format is *area code + 7 digit number + 1 + 00*.)
- Set the Terminal Endpoint Identifier (TEI) to Dynamic (this tells the switch that you can accept any TEI value from 64 to 126.)
- Set Ring to Yes (this tells the switch to send an alerting message to your CPE when there is an incoming call.)
- Set the maximum keys to 10 (this tells the switch how much memory to allocate for features.)
- Set Key system (EKTS) option to No (this tells the switch that you are not a key system.)
- Place the lower layer compatibility option for data on the B-channels (this tells the switch that your CPE may utilize the lower layer compatibility information element for data on the B-channels.)
- Place calling subaddress option for data on the B-channels (this tells the switch that your CPE will send a subaddress.)
- Place called subaddress option for data on the B-channels (this tells the switch that your CPE can receive a subaddress.)

The Telephone Company will also need to know any additional data features that you require on your ISDN lines.

FAX-PAGE 5
------------

Northern Telecomm DMS-100 BC-35 National ISDN 1

- 2B1Q line code
- 2B&D line
- B1 - set circuit switch to YES; set BEARER RESTRICTION to NOPMD (no packet)
  - functional version 2; (PVC 2)
  - set SPID-SUFFIX to 1
  - set TEI to DYNAMIC
  - set RING to YES
  - set MAXKEYS to 10
  - set EKTS to NO
  - set data option: PROVLLC CMDATA (lower layer compatibility)
  - set data option: PROVCGS CMDATA (calling subaddress)
  - set data option: PROVCDs CMDATA (called subaddress)
- B2 - set circuit switch to YES; set BEARER RESTRICTION to NOPMD (no packet)
  - functional version 2; (PVC 2)
  - set SPID-SUFFIX to 1
  - set TEI to DYNAMIC
  - set RING to YES
  - set MAXKEYS to 10
  - set EKTS to NO
  - set data option: PROVLLC CMDATA (lower layer compatibility)
  - set data option: PROVCGS CMDATA (calling subaddress)
  - set data option: PROVCDs CMDATA (called subaddress)

list any additional data features required for B1 and B2

## Appendix G — One Year Limited Warranty

MUSICAM USA, formerly known as Corporate Computer Systems (CCS) warrants to the original purchaser that each of its hardware products and all component s therein contained will be free from defects in materials and/or workmanship for one (1) year from the date of purchase. Any warranty hereunder is extended only to the original purchaser and is not assignable.

In the event of a malfunction or other indication of failure attributable directly to faulty workmanship and/or material, MUSICAM USA will, at its option, repair or replace said device or components, to whatever extent it shall deem necessary to restore said device to proper operating condition.

Before returning a device for repair, the customer must call MUSICAM USA at (732)739-5600 and obtain a return authorization number. This number should be included with the customer's mailing address and telephone number when the product is returned.

**Products must be returned to:**  
**MUSICAM USA**  
**670 North Beers St. Building #4**  
**Holmdel, NJ 07733**  
**U.S.A.**  
**Attention: Warranty Repair**

During the first year after the date of purchase, all labor and materials will be provided without charge. There shall be no warranty for either parts or labor after the expiration of 1 year from the date of purchase.

Units must be returned postage pre-paid. It is recommended that the unit be insured and securely packed when shipped. Units returned which are out of warranty will be repaired or replaced (at the option of MUSICAM USA) and the customer will be charged for parts and labor at current rates.

Units will be returned to the customer after repair or replacement has been completed by carrier and method chosen by MUSICAM USA to any destination within the United States of America.

Should a customer desire some other specific form of conveyance, or be located beyond the US borders, then the customer must bear the cost of return shipment.

The customer shall be solely responsible for the failure of any MUSICAM USA hardware computer product, or component thereof, resulting from accident, abuse or misapplication of the product, and MUSICAM USA assumes no liability as a consequence of such events under the terms of this Warranty.

While every effort on the part of MUSICAM USA has been made to provide clear and accurate technical information on the application of its products, MUSICAM USA assumes no liability in any events which may arise from the use of said technical information.

**THERE ARE NO OTHER WARRANTIES MUSICAM USA DISCLAIMS ALL OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHERS, WHICH VARY FROM STATE TO STATE.**

**NO LIABILITY FOR CONSEQUENTIAL DAMAGES IN NO EVENT SHALL MUSICAM USA OR ANY OF ITS SUPPLIERS BE LIABLE FOR ANY DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF DATA COMMUNICATIONS, LOSS OF BUSINESS INFORMATION, OR OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF, OR INABILITY TO USE, THIS MUSICAM USA PRODUCT, EVEN IF MUSICAM USA HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. BECAUSE SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.**